



Rebuildable, Rechargeable Pulsation Dampeners

Models 701550-701557 701607

ORDERING INFORMATION

All models must be precharged before operation.

Add .800 to base part number and indicate desired pre-charge on purchase order.

Note: A handling charge will apply.

FEATURES

- Poppet reinforced bladder for durability.
- Nitrogen pre-charged to eliminate moisture and provide smooth bladder compression and pressure release.
- Sealed charging valve for positive pressure lock.
- Optional bladder materials for liquid compatibility and 316 stainless steel construction for strength and liquid compatibility.
- Convenient rebuildable style with top access permits replacing bladder without disturbing plumbing.
- Absorbs system shocks while minimizing excessive pipe vibration, water hammering and pressure fluctuations.

SHIPMENT REGULATIONS

- Pre-charged Prrrr-O-Lators are defined as hazardous articles. Uncharged Prrrr-O-Lators requires no special handling and can be shipped via standard shipping methods.
- All domestic shipments of hazardous articles must follow Department of Transportation CFR 49, parts 100 to 185 regulations (DOT).
- International shipments of hazardous articles must follow either International Air Transport Association regulation (IATA) or International Maritime Dangerous Goods Codes (IMDG).

⚠ CAUTIONS AND WARNINGS

All High Pressure Systems require a primary pressure regulating device (i.e. regulator, unloader) and a secondary pressure relief device (i.e. pop-off valve, relief valve). Failure to install such relief devices could result in personal injury or damage to pump or property. CAT PUMPS does not assume any liability or responsibility for the operation of a customer's high pressure system.

Read all CAUTIONS and WARNINGS before commencing service or operation of any high pressure system. The CAUTIONS and WARNINGS are included in each service manual and with each Accessory Data sheet. CAUTIONS and WARNINGS can also be viewed online at www.catpumps.com/cautions-warnings or can be requested directly from CAT PUMPS.

WARRANTY

View the Limited Warranty on-line at www.catpumps.com/warranty.

SPECIFICATIONS

	U.S. Measure	Metric Measure
MODEL 701550		
Maximum Flow	100 gpm	(378 l/m)
Pressure Range	100 - 3365 psi	(7 - 232 bar)
Maximum Temperature	122°F	(50°C)
Volume	122 cu. in.	(2.00 L)
Safety Factor	4/1	(4/1)
Bladder Construction	NBR	(NBR)
Port Size	1-1/2" NPTF	(1-1/2" NPTF)
Diameter	6.2"	(158 mm)
Length	16.54"	(420 mm)
Weight	50.7 lbs.	(23.0 kg)
MODEL 701555		
Maximum Flow	100 gpm	(378 l/m)
Pressure Range	100 - 6350 psi	(7 - 438 bar)
Maximum Temperature	122°F	(50°C)
Volume	60 cu. in.	(0.98 l)
Safety Factor	4/1	(4/1)
Bladder Construction	NBR	(NBR)
Port Size	1" NPTF	(1" NPTF)
Diameter	5.8"	(146 mm)
Length	10.79"	(274 mm)
Weight	48.5 lbs.	(22.0 kg)
MODEL 701557		
Maximum Flow	320 gpm	(1211 l/m)
Pressure Range	100 - 1275 psi	(7 - 88 bar)
Maximum Temperature	122°F	(50°C)
Volume	214 cu. in.	(3.50 l)
Safety Factor	4/1	(4/1)
Bladder Construction	NBR	(NBR)
Port Size	1-1/2" NPTF	(1-1/2" NPTF)
Diameter	5.5"	(141 mm)
Length	16.93"	(430 mm)
Weight	41.9 lbs.	(19.0 kg)

MATERIAL CODES: NBR=Medium Nitrile (Buna-N)

"Customer confidence is our greatest asset"

MODEL 701607

Maximum Flow	320 gpm	(1211 l/m)
Pressure Range	100 - 1275 psi	(7 - 88 bar)
Maximum Temperature	122°F	(50°C)
Volume	214 cu. in.	(3.50 l)
Safety Factor	4/1	(4/1)
Bladder Construction	FPM	(FPM)
Port Size	1-1/2" NPTF	(1-1/2" NPTF)
Diameter	5.5"	(141 mm)
Length	16.93"	(430 mm)
Weight	41.9 lbs.	(19.0 kg)

MATERIAL CODES: FPM=Fluorocarbon

WARNING

Do not charge Prrrr-O-Lators (Pulsation Dampeners) with oxygen. Oxygen may cause an explosion causing personal injury, death or property damage.

1. Use nitrogen only when charging pulsation dampeners, DO NOT USE OXYGEN.
 2. Use proper charging tools to charge pulsation dampeners.
 3. Charge pulsation dampener within specifications stated on data sheet to assure proper pulsation dampening and prevent failure of bladder.
-

SELECTION

The Pulsation Dampener should be selected to match the flow and pressure requirements of the system and satisfy the liquid compatibility. Although all models will operate down to 100 PSI, it is most economical to select a Pulsation Dampener closest to but higher than your desired system pressure.

INSTALLATION

The Pulsation Dampener should be mounted in a vertical position and teed directly onto the pump discharge manifold for optimum pulsation dampening and to avoid system vibration damage.

When using a By-Pass Hose with liquid returning to the inlet, mount the Pulsation Dampener before the Pressure Reducing Valve. If this is not possible, then mount the Pulsation Dampener after the Pressure Unloading Valve to prevent pressure spikes to the pump inlet.

When using a Inlet Pressure Regulator, mount the Pulsation Dampener downstream from the regulator to assure optimum performance of the regulator.

OPERATION

The Pulsation Dampener must be pre-charged with **NITROGEN ONLY** before operation. Be certain the charging valve cap at the top of the accumulator is securely tightened to assure no loss of pressure during operation.

With the system turned on, liquid enters the fluid port of the Pulsation Dampener. The liquid compresses the nitrogen charged bladder, which in turn absorbs the liquid kinetic energy, thus reducing the pressure pulsations.

At standard 70°F (20°C), optimum pulsation dampener performance is obtained with a **pre-charge of 70% to 80%** of the operating pressure.

Check the pre-charge every 12 months for normal operation and more frequently for continuous-duty operation.

NOTE: Up to 50 PSI pre-charge pressure can be lost during the checking of your pre-charge.

NOTE: A gas regulator must be mounted between the nitrogen tank and the hose connection from the Filling and Gauging Assembly to enable you to regulate the pre-charge and to prevent excessive pressure being transmitted directly to the Pulsation Dampener. This over pressurization will void the warranty.

MAINTENANCE

Check the pre-charge every 12 months for normal operation and more frequently for continuous-duty operation.

If pulsation is noticed, relieve the pre-charge and inspect the bladder for wear. Replace as needed.


FILLING AND GAUGING INSTRUCTIONS

To Add Pre-charge

1. Mount Filling and Gauging Assembly preferably onto a regulated nitrogen supply.
2. Open ball valve (handle inline with valve).
3. Thread adapter collar hand tight onto top of Pulsation Dampener.
4. Open main valve on nitrogen supply.
5. Slowly increase pressure from the regulator to Pulsation Dampener.
6. Close ball valve and regulated supply when desired pre-charge is reached.
7. Remove adapter collar from Pulsation Dampener (a small amount of nitrogen will escape from hose as collar is removed).
8. Replace charging valve cap and tighten securely.
9. Slowly open ball valve to purge all fittings of nitrogen before removing Filling and Gauging Assembly.

To Remove Nitrogen

1. Do not mount Filling and Gauging Assembly to a nitrogen supply.
2. Remove the dust cap.
3. Remove charging valve cap from top of Pulsation Dampener.
4. Close ball valve (handle perpendicular to valve).
5. Secure adapter collar onto top of Pulsation Dampener.
6. Slowly open ball valve and release the nitrogen from the Pulsation Dampener.
7. When desired pre-charge pressure is reached, close the ball valve.
8. Remove the adapter collar from the Pulsation Dampener (a small amount of nitrogen will escape from the hose).
9. Replace the charging valve cap and tighten securely.



REPLACING THE BLADDER

Disassembly

1. Remove the dust cap at the top of the Pulsation Dampener.
2. Remove the charging valve cap.
3. Release the nitrogen precharge using the Filling and Gauging Assembly as described under TO REMOVE NITROGEN steps 4 through 8.
4. Using a soft mallet, tap threaded gas fitting to drive gas cap below snap ring.

NOTE: If the gas cap will not press down after the pre-charge has been released, the charging valve may be plugged. Remove the charging valve to ensure all gas has been released. Then replace valve.

5. Using a screw driver, carefully remove the first segment of the three piece snap ring. The other two pieces can be removed by hand.
6. Grasp the gas cap and bladder assembly by the top hex nut with a locking plier and carefully remove from the body. Keep aligned to avoid damage to the bladder.
7. Inspect the bladder for cracks, punctures or deformity.
8. Remove bladder from gas cap, then inner and outer o-rings. Replace if damaged or worn.

Reassembly


1. Install the new inner o-ring into the groove on the gas cap.
2. Install the new bladder over the o-ring onto the gas cap.
3. Install the new outer o-ring into the groove in the body of the Pulsation Dampener.
4. Lubricate both the outer o-ring and bladder and press the bladder and gas cap assembly into the body.
5. Using a soft mallet tap the gas cap into the body until the snap ring groove is exposed, then insert the three sections of snap ring. Be certain the gas cap is pulled up squarely in position and gas valve is fully exposed.
6. Pre-charge Pulsation Dampener as described under TO ADD PRE-CHARGE steps 1 through 9.

⚠ WARNING

Do not charge Prrrr-O-Lators (Pulsation Dampeners) with oxygen. Oxygen may cause an explosion causing personal injury, death or property damage.

1. Use nitrogen only when charging pulsation dampeners, DO NOT USE OXYGEN.
 2. Use proper charging tools to charge pulsation dampeners.
 3. Charge pulsation dampener within specifications stated on data sheet to assure proper pulsation dampening and prevent failure of bladder.
-
7. Replace dust cap over top of Pulsation Dampener.

EXPLODED VIEW



PARTS LIST

ITEM	PN	MATL	DESCRIPTION	MODEL USED	QTY
1	—	NY	Cap, Dust (100 GPM)	701550	1
	—	NY	Cap, Dust (100 GPM)	701555	1
	—	NY	Cap, Dust (320 GPM)	701557, 701607	1
2	—	SS	Ring, 3-piece	All	1
3	—	SS	Cap, Charging Valve	All	1
4	—	SS	Valve, Charging	All	1
5	—	SS	Cap, Gas	All	1
6	—	NBR	O-Ring, Inner	All	1
	—	FPM	O-Ring, Inner	All	1
7	—	NBR	Bladder	All	1
	—	FPM	Bladder	All	1
8	—	NBR	O-Ring, Outer	All	1
	—	FPM	O-Ring, Outer	All	1
9	—	SS	Body	All	1
10	702455	—	Button Bladder	701557	1
	—	701540	FPM Bladder Kit (Inclds: 6,7,8)	701607	1
—	701549	NBR Bladder Kit (Inclds: 6,7,8)	701550	1	
—	701556	NBR Bladder Kit (Inclds: 6,7,8)	701555	1	
—	701558	NBR Bladder Kit (Inclds: 6,7,8)	701557	1	
—	34570	—	Filling and Gauging Assy	All	1
—	702038	SS	Charging Assy (Inclds: 3,4)	All	1

Italics are optional items.

MATERIAL CODES (Not Part of Part Number):
 FPM=Fluorocarbon NBR=Medium Nitrile (Buna-N)
 NY=Nylon SS=316SS

World Headquarters

CAT PUMPS

1681 - 94th Lane N.E. Minneapolis, MN 55449-4324

Phone (763) 780-5440 — FAX (763) 780-2958

e-mail: techsupport@catpumps.com

www.catpumps.com

International Inquiries

FAX (763) 785-4329

e-mail: intlsales@catpumps.com



The Pumps with Nine Lives

CAT PUMPS (U.K.) LTD.

1 Fleet Business Park, Sandy Lane, Church Crookham

FLEET, Hampshire, GU52 8BF, England

Phone Fleet 44 1252-622031 — Fax 44 1252-626655

e-mail: sales@catpumps.co.uk

N.V. CAT PUMPS INTERNATIONAL S.A.

Heiveldekens 6A, B-2550 Kontich, Belgium

Phone 32-3-450.71.50 — Fax 32-3-450.71.51

e-mail: cpi@catpumps.be www.catpumps.be

CAT PUMPS DEUTSCHLAND GmbH

Buchwiese 2, D-65510 Idstein, Germany

Phone 49 6126-9303 0 — Fax 49 6126-9303 33

e-mail: catpumps@t-online.de www.catpumps.de